

Wrap-It Link™ Assembly Instructions



1. Confirm continuity,
insert link through lines...



2. Wrap-It™ through riser...



3. Wrap-It™ through lines
and riser a **second** time...



4. Wrap-It™ through lines
and riser a **third** time...



5. Place end through loop
holding ring...



6. Lock running end by
pulling ring through loop.



7. Pull to tighten knot...



8. Pull lines and riser to
evenly distribute 3 wraps.



9. Rotate ring into riser
and shape link as shown
above.

Precision
aerodynamics, inc.

727 Rankin Ave. N., P. O. Box 386, Dunlap, TN 37327, USA
423-949-4688 423-949-5174 (fax)
www.aerodynamics.com